

ECP 1000 Event Control Panel

Configuration

Changing the Backlight Intensity

1. From the default screen, press the Menu button.
2. Press the Next button.
3. Rotate the adjust knob until the backlight is at the desired intensity.

Performing a System Reset

1. From the default screen, press the Menu button twice.
2. Press the Next button.
3. Press the Take button.

Programming the ECP 1000

Warning: You cannot control SGS 408 effects when the ECP 1000 is in program mode.

1. Press the Menu button three times.
2. Press the Next button.
3. Program the ECP 1000 through the SGS 408 Control Program.
4. When you are finished programming the ECP 1000, press the Menu button.

Operation

Applying a Cut

1. Press the Cut button.
2. Press the screen selection button that corresponds to the screens you want to switch.
3. Press the Take button.

Applying a Dissolve

1. Press the Dissolve button.
2. Press the screen selection button that corresponds to the screen you want to switch.
3. If desired, change the duration by turning the Adjust knob.
4. Press the Take button or use the T-bar control.

Applying a Title

1. Press the Title button.
2. Press the screen selection button that corresponds to the screens you want to title.
3. If desired, change the duration by turning the Adjust knob.
4. Press the Take button or use the T-bar control.
5. When you want the title to end, press the Take button again.

Operation, cont'd.

Applying a Wipe

1. Press the effects button that is programmed to perform the wipe you want.
2. Select the screens to which the effect will be applied. See the note below.
3. If desired, change the duration by turning the Adjust knob.
4. If desired, press the Soft Edge button.
5. Press the Take button or move the T-bar control.

Note: If this is the first time an effect has been selected after the ECP 1000 is installed or a system reset is performed, the number of screen selection buttons that light is based on the type of wipe that was selected. If you press a two-screen effect, buttons 1 and 2 will light.

Otherwise, the screen selection buttons that were selected the last time an effect was selected will light.

If you want to deselect a screen that is lit and select a screen that is not lit, press the button that you want to turn off. If buttons 1 and 2 are lit and you want to light buttons 1 and 3 instead, press button 2.



Extron Electronics, U.S.A.

1230 South Lewis Street
Anaheim, CA 92805
714.491.1500 FAX 714.491.1517
U.S.A.

Extron Electronics, Europe

Beeldschermweg 6C
3821 AH Amersfoort
+31.33.453.4040 FAX +31.33.453.4050
The Netherlands

Extron Electronics, Asia

135 Joo Seng Road, #04-01
PM Industrial Building, Singapore 368363
+65.383.4400 FAX +65.383.4664
Singapore

General Information

- * Normally, the LCD screen displays the attached screens (based on the connected ports) and the default effect duration.
- * During a wipe, the LCD screen displays a percentage count as the effect is completed.
- * All buttons that are available, based on the selections you made, are backlit.

Installation

- * Use a 9-pin, straight-through RS-232 cable.
- * The cable should be no more than 50 ft. (15.24 m) long.

33-568-01 A
09 00
Printed in USA